

## Příloha č. 7 - Input list

	instrument	co?	stand
1.	Kick	shure BETA 81	none
2.	SN	Shure SM 57	small
3.	HH	AKG 451	small
4.	tom	EW 604/904	none
5.	F tom	EW 604/904	none
6.	OH	AKG 451	tall
7.	OH	AKG 451	tall
8.	double Bass	XLR	small
9.	KEY L	DI	small
10.	KEY R	DI	none
11.	spare		
12.	spare		
13.	trumpet	Shure SM 57	tall
14.	trumpet	Shure SM 57	tall
15.	trumpet	Shure SM 57	tall
16.	trumpet	Shure SM 57	tall
17.	trombone	Shure SM 57	tall
18.	trombone	Shure SM 57	tall
19.	trombone	Shure SM 57	tall
20.	trombone	Shure SM 57	tall
21.	saxophone	Shure SM 57	small
22.	saxophone	Shure SM 57	small
23.	saxophone	Shure SM 57	small
24.	saxophone	Shure SM 57	small
25.	saxophone	Shure SM 57	small
26.	spare		
27.	spare		
28.	spare		
29.	solo VOC 1	EW 965 wireless	tall
30.	solo VOC 2	EW 945 wireless	tall
31.	"spíkr" 1.	EW 945 wireless	tall
32.	"spíkr" 2.	EW 945 wireless	tall
33.	spare	EW 945 wireless	tall
34.	spare		
35.	Playback L	DI	
36.	Playback R	DI	
37.	Mix L NONAME	XLR	
38.	Mix R NONAME	XLR	
39.	Mix Bass NONAME	XLR	
40.	Mix L T.Klus	XLR	
41.	Mix R T.Klus	XLR	
42.	Mix B T.Klus	XLR	
43.	sbor	AKG C3000	
44.	sbor	AKG C3000	
45.	sbor	AKG C3000	
46.	sbor	AKG C3000	

Priloha c. 7 - Input list.xls

47.	video	XLR	
48.	video	XLR	